

TECHNICAL DATASHEET

STEEL PUTTY

ART. NO: #138.587 (0.9KG)

STEEL PUTTY is a unique filler with a very high degree of hardness designed for filling car body edges, mudguards and PU-bonded panels. Can also be used for repairing rust holes on filler necks, door corners and exterior mirrors, making it extremely versatile across various applications. BPO pink hardener included.

FEATURES

- ✓ High degree of hardness
- ✓ Smooths and fills polyurethane bonded panels
- ✓ Flexible with no shrinkage
- ✓ Absorbs vibrations and oscillations
- ✓ Unaffected by most oils and acids
- ✓ Suitable for special and extraordinary repairs (old-timers)
- ✓ Easily fills deep and uneven areas where tin plating is not possible
- ✓ High heat stability

AREA OF APPLICATION

For use during general automotive bodywork and reparation. Ideal for filling large holes and uneven surfaces in hard to reach areas where tin plating is not possible.

CONDITIONS OF USE AND CONFORMITY

The before mentioned technical data and information, especially the recommendations for applying and using our products, are based on our current knowledge and experience when applied under normal conditions. In practice, the materials, surfaces or site conditions are so different that no warranty regarding the working results or liability, arising out of any relationship, can be inferred neither from this information nor from a verbal consultation, except we are charged with intent or gross negligence. In this case the user is obliged to prove that he has informed us about all points required for a proper and promising judgment in writing, in time and completely. Patent rights of any third party are to be observed. Furthermore, our general sales and delivery Terms and Conditions and the latest Technical Data Sheet, which should be demanded, apply.

HEALTH & SAFETY

See Safety Data Sheet and labels for additional safety information and handling instructions. Directions for handling and waste disposal are in our Material Safety Data Sheet and the specifications of the Employers Liability Insurance Association for the chemical industry. Wear appropriate PPE such as eye and skin protection. In the event of injury, see first aid procedures on SDS. Always observe all applicable precautions and follow good safety and hygiene practices.

VOC INFORMATION		
Category	Putties & Fillers	
	g/L	LBS/GAL
VOC	70.0	0.58
Density	1400	11.68

PRODUCT DATA

Nature: Polyester body putty

Color: Aluminum

Shelf Life: 6 months (sealed in original container)

between 18 - 20°C

Package: 0.9 KG + BPO Pink Hardener

Number per case: 12

Safety Data Sheet (SDS) is available on our website



TECHNICAL DATASHEET

CAUTION

FOR USE ON STEEL SURFACES ONLY. DO NOT APPLY ON ZINC AND ALUMINUM SURFACES.

HANDLING



PREPARATION

- 1. Clean and degrease the entire panel to be repaired with soap and water, followed by a mild cleaning solvent.
- 2. Thoroughly dry the surface before repairing. Keep the repair area small.
- 3. Sand all traces of rust, old putty, nitrocellulose paint, 1K acrylic synthetic paint and any layers reactive to cleaning solvent.
- 4. Keep the repair area small. Sand the entire repair area with P40. Use P80 to remove coarse sanding marks and bevel the coat inward toward the repair.

N.B. Since all polyester resin-based materials are sensitive to moisture, it is preferable to clean the steel by sandblast before applying the filler in order to avoid the formation of blisters or pinholes.



MIXING

- 1. Stir filler and knead the cream hardener before using.
- 2. Add 2 to 3% by weight of BPO pink cream hardener (add a ribbon of cream hardener from edge to edge across the center of a 4" diameter puddle of putty).
- 3. Mix thoroughly until uniform color is achieved.

N.B. An overdose of cream hardener should be avoided. This may result in bleeding through and color changes in the top coat. Insufficient addition of hardener may result to a sticky resin layer on the surface.



WORKING TIME

3 - 5 minutes @ > 21°C (>70°F)

REACTION TEMPERATURE

At least >10°C (>50°F) and up to 90% relative humidity.

N.B. In winter it is preferable to warm the metal surface using infrared lamps (or other heat lamps) before application.



APPLICATION

Apply thin layers of the putty and spread evenly and smoothly. Do not blob on or apply all at once.



DRYING TIMES

20 - 25 minutes at > 21°C (>70°F) room temperature.

N.B. The heat will shorten the cure time while the cold will lengthen it.



SANDING

Before sanding, the product should cure at least 20 - 25 minutes at an ambient temperature of 21° C (70° F) or more.

First Sanding: P80 - P100 Second Sanding: P120 - P180 Final Sanding: P180 - P240

3800, TransCanada Highway, Pointe-Claire (Qc) H9R 1B1 T 514 745-5959 • F 514 745-6802 • www.carworx.net